

# Glutamate Assay Kit

(Catalog #K629-100; 100 reactions; Store kit at -20°C)

## I. Introduction:

Glutamate, one of the two acidic proteinogenic amino acids, is also a key molecule in cellular metabolism. In humans, glutamate plays an important role both in amino acid degradation and disposal of excess or waste nitrogen. Glutamate is the most abundant swift excitatory neurotransmitter in the mammalian nervous system. It is believed to be involved in learning and memory and has appeared to be involved in diseases like amyotrophic lateral sclerosis, lathyrism, autism, some forms of mental retardation and Alzheimer's disease. Glutamic acid is also present in a wide variety of foods, and has been used as a flavor enhancer in food industry. BioVision's Glutamate Assay Kit provides a sensitive detection method of the glutamate in a variety of samples. The glutamate Enzyme Mix recognizes glutamate as a specific substrate leading to proportional color development. The amount of glutamate can therefore be easily quantified by colorimetric (spectrophotometry at  $\lambda = 450$  nm) method.

## II. Kit Contents:

Components	K629-100	Cap Code	Part No.
Glutamate Assay Buffer	25 ml	WM	K629-100-1
Glutamate Enzyme Mix	1 vial	Green	K629-100-2
Glutamate Developer	1 vial	Red	K629-100-3
Glutamate Standard (0.1M)	0.1 ml	Yellow	K629-100-4

## III. Storage and Handling:

Store the kit at -20°C, protect from light. Allow Assay Buffer to warm to room temperature before use. Briefly centrifuge vials before opening. Read the entire protocol before performing the assay.

## IV. Reagent Reconstitution and General Consideration:

Reconstitute Glutamate Enzyme Mix with 220  $\mu$ l Assay Buffer. Reconstitute Glutamate developer with 820  $\mu$ l of ddH<sub>2</sub>O. Pipette up and down several times to completely dissolve the pellet into solution (**Don't vortex**). Aliquot enough Glutamate Enzyme Mix (2  $\mu$ l per assay) for the number of assays to be performed in each experiment and freeze the stock solution immediately at -20°C for future use. The Glutamate Enzyme Mix is stable for up to 2 months at -20°C after reconstitution or freeze-thaw cycle less than 5 times.

Ensure that the Assay Buffer is at room temperature before use. Keep the Glutamate Enzyme Mix on ice during the assay and protect from light.

## V. Glutamate Assay Protocol:

### 1. Glutamate Standard Curve:

Dilute 10  $\mu$ l of the 0.1M Glutamate standard with 990  $\mu$ l Assay Buffer to generate 1 mM standard Glutamate. Add 0, 2, 4, 6, 8, 10  $\mu$ l of the diluted Glutamate standard into a 96-well plate in duplicate to generate 0, 2, 4, 6, 8, 10 nmol/well standard. Bring the volume to 50  $\mu$ l with Assay buffer.

### 2. Sample Preparations:

Tissues or cells ( $1 \times 10^6$ ) can be homogenized in 100  $\mu$ l Assay Buffer. Centrifuge to remove insoluble material at 13,000 g, 10 minutes. 10-50  $\mu$ l serum samples can be directly diluted in the Assay Buffer. Bring sample wells to 50  $\mu$ l/well with Assay Buffer in a 96-well plate. Prepare a parallel sample well as the background control. We suggest testing several doses of your sample to make sure the readings are within the standard curve range.

## 3. Reaction Mix:

Mix enough reagents for the number of assays to be performed. For each well, prepare a total 100  $\mu$ l Mix containing:

Reaction Mix	Background Control Mix
90 $\mu$ l Assay Buffer	92 $\mu$ l Assay Buffer
8 $\mu$ l Glutamate Developer	8 $\mu$ l Glutamate Developer
2 $\mu$ l Glutamate Enzyme Mix	

Add 100  $\mu$ l of the Reaction Mix to each well containing the Glutamate Standard and test samples. To the background control well, add 100  $\mu$ l of background control mix. Mix well. Incubate the reaction for 30 min at 37°C, protected from light.

## 4. Measure OD at 450 nm in a microplate reader.


5. Correct background by subtracting the value derived from background control from all sample readings (The background reading can be significant and must be subtracted from sample readings). Plot Glutamate standard Curve, Glutamate concentrations of the test samples can then be calculated:

$$C = S_a/S_v \text{ nmol}/\mu\text{l, or mM}$$

Where:  $S_a$  is the sample amount of unknown (in nmol) from standard curve,  $S_v$  is sample volume ( $\mu$ l) added into the wells.

L-Glutamic acid Molecular Weight is 147.13 g/mol.

**Glutamate Standard Curve**



## RELATED PRODUCTS:

NAD/NADH Quantification Kit	NADP/NADPH Quantification Kit
ADP/ATP Ratio Assay Kit	Ascorbic Acid Quantification Kit
Glucose Assay Kit	Fatty Acid Assay Kit
Ethanol Assay Kit	Uric Acid Assay Kit
Pyruvate Assay Kit	Lactate Assay Kit/ II
Creatine Assay Kit	Creatinine Assay Kit
Ammonia Assay Kit	Free Glycerol Assay Kit
Triglyceride Assay Kit	Hemin Assay Kit
Choline/Acetylcholine Quantification Kit	Total Antioxidant Capacity (TAC) Assay Kit
Sarcosine Assay Kit	L-amino Acid Assay Kit
Nitric Oxide Assay Kit	Glutathione Detection Kit
ADP & ATP Colorimetric Kits	ADP & ATP fluorometric Kits

**FOR RESEARCH USE ONLY! Not to be used on humans.**

## GENERAL TROUBLESHOOTING GUIDE:

Problems	Cause	Solution
Assay not working	<ul style="list-style-type: none"> <li>• Use of ice-cold assay buffer</li> <li>• Omission of a step in the protocol</li> <li>• Plate read at incorrect wavelength</li> <li>• Use of a different 96-well plate</li> </ul>	<ul style="list-style-type: none"> <li>• Assay buffer must be at room temperature</li> <li>• Refer and follow the data sheet precisely</li> <li>• Check the wavelength in the data sheet and the filter settings of the instrument</li> <li>• Fluorescence: Black plates (clear bottoms) ; Luminescence: White plates ; Colorimeters: Clear plates</li> </ul>
Samples with erratic readings	<ul style="list-style-type: none"> <li>• Use of an incompatible sample type</li> <li>• Samples prepared in a different buffer</li> <li>• Samples were not deproteinized (if indicated in datasheet)</li> <li>• Cell/ tissue samples were not completely homogenized</li> <li>• Samples used after multiple free-thaw cycles</li> <li>• Presence of interfering substance in the sample</li> <li>• Use of old or inappropriately stored samples</li> </ul>	<ul style="list-style-type: none"> <li>• Refer data sheet for details about incompatible samples</li> <li>• Use the assay buffer provided in the kit or refer data sheet for instructions</li> <li>• Use the 10 kDa spin cut-off filter or PCA precipitation as indicated</li> <li>• Use Dounce homogenizer (increase the number of strokes); observe for lysis under microscope</li> <li>• Aliquot and freeze samples if needed to use multiple times</li> <li>• Troubleshoot if needed, deproteinize samples</li> <li>• Use fresh samples or store at correct temperatures till use</li> </ul>
Lower/ Higher readings in Samples and Standards	<ul style="list-style-type: none"> <li>• Improperly thawed components</li> <li>• Use of expired kit or improperly stored reagents</li> <li>• Allowing the reagents to sit for extended times on ice</li> <li>• Incorrect incubation times or temperatures</li> <li>• Incorrect volumes used</li> </ul>	<ul style="list-style-type: none"> <li>• Thaw all components completely and mix gently before use</li> <li>• Always check the expiry date and store the components appropriately</li> <li>• Always thaw and prepare fresh reaction mix before use</li> <li>• Refer datasheet &amp; verify correct incubation times and temperatures</li> <li>• Use calibrated pipettes and aliquot correctly</li> </ul>
Readings do not follow a linear pattern for Standard curve	<ul style="list-style-type: none"> <li>• Use of partially thawed components</li> <li>• Pipetting errors in the standard</li> <li>• Pipetting errors in the reaction mix</li> <li>• Air bubbles formed in well</li> <li>• Standard stock is at an incorrect concentration</li> <li>• Calculation errors</li> <li>• Substituting reagents from older kits/ lots</li> </ul>	<ul style="list-style-type: none"> <li>• Thaw and resuspend all components before preparing the reaction mix</li> <li>• Avoid pipetting small volumes</li> <li>• Prepare a master reaction mix whenever possible</li> <li>• Pipette gently against the wall of the tubes</li> <li>• Always refer the dilutions in the data sheet</li> <li>• Recheck calculations after referring the data sheet</li> <li>• Use fresh components from the same kit</li> </ul>
Unanticipated results	<ul style="list-style-type: none"> <li>• Measured at incorrect wavelength</li> <li>• Samples contain interfering substances</li> <li>• Use of incompatible sample type</li> <li>• Sample readings above/below the linear range</li> </ul>	<ul style="list-style-type: none"> <li>• Check the equipment and the filter setting</li> <li>• Troubleshoot if it interferes with the kit</li> <li>• Refer data sheet to check if sample is compatible with the kit or optimization is needed</li> <li>• Concentrate/ Dilute sample so as to be in the linear range</li> </ul>
<p><b>Note:</b> The most probable list of causes is under each problem section. Causes/ Solutions may overlap with other problems.</p>		